

SNO CONE MACHINE



BLADE ADJUSTMENT INSTRUCTIONS

#382SCM350R, #382SCM250, #382SCM350TUB

Blade Maintenance & Replacement Instructions


Remove the Cutting Head (Caution: Sharp Blades)

Note: you may have to remove the motor cover to access cutting head.

1. Turn off the POWER switch.
2. Rotate the cutting head until the setscrew is accessible through the discharge opening located inside the top panel of the tub frame.
3. Use a 1/8" hex wrench to loosen the set-screws. *(Note: size of hex wrench may vary, or other screwdriver may be necessary).*
4. Carefully slide the cutting head off the motor shaft and remove the cutting head out of the top side, inlet, of the ice horn.

Cutting Head Blade Replacement

5. Remove the two screws per blade.
6. Lift the old blades out.
7. Position the new blades on the head with the cutting edge extending between 1/32" to 1/16" out from the cutting head surface. This setting will determine the size of the ice. The more blade that is exposed beyond the head will create a coarser ice chip.



8. Use the blade screws to secure the blades to the head.

Installing the Cutting Head

9. Slide the cutting head down into the ice horn with the coupler end first.
10. As the cutting head is slipped onto the motor shaft, align the setscrews to the flat location of the motor shaft.
11. Tighten the setscrews with a 1/8" hex wrench. *(Note: size of hex wrench may vary, or other screwdriver may be necessary).*
 - a. It is important to ensure the screws are tight.
12. Machine is now ready for use.
13. Reinstall motor cover.