

Rev. C-35806

^{***} Changed to 5 - 75s for V2.7 and beyond

Main		Changing the	program after the	e litan has been j	programmed.		
Language	Enter Portuguese	Spanish 🖡	French				
t or ₹						CHANGING SETTING	
Detergent Prime	Enter to Start	Enter to Stop				All settings change the same	
t or ↓ Pinco Primo	Enter to Start	Entor to Stop				modify any setting. The curs	
Rinse Prime ↑ or	Enter to Start	Enter to Stop				flashing block format or an u Use ↑ or ↓ to modify the set	•
Sanitizer Prime	Enter to Start	Enter to Stop				save the result and clear the	•
♠ or ♣						move the underscore when c	
Det. SP input	Det. C= concentra	ation or P = Probeles	ss SP = Set point	INPUT = reading	the water		hanging the display hame.
↑ or ↓							
Rack Count							
t or ↓	Entor to Stort	Enter to Stop					
Descale ↑ or ↓	Enter to Start	Enter to Stop	To get out of	programming sub	pheadings hit		
System Access			•	to get to program	•		
Enter				hit the left arrow			
	-				•		
Enter code				er Left to get out			
Enter			programming				
Programming	Enter Rack count reset	Control mode	Switchovor Alarm		Triggor Mode	<u>Co. Name</u>	nc - Entor Now Codo
t or ↓	Enter	auto switchover	inactive	Door	Det. / Rinse	? <u>Alarin Volur</u> ? 0 -10	to change code
- 01 1	left to reset	Concentration	Active	Conveyor		♦ and ♦	to onlange oode
		Probe-less			Det. Only		
					Rinse Only		
Concentration	Enter Cono Sot Doint			Feed Limit			
Concentration ↑ or ↓	Enter <u>Conc. Set Point</u> ◀	Feed Rate 0 - 10	<u>Alarm Delay</u> 5sec - 10min	5sec - 10min			
• 01 •		0 - 10	0360 - 1011111	0360 - 1011111			
Probeless	Enter Recharge Time	D=Dead Cycles ↓	C = Dwell Time	Initial Charge	Charge Clocl □	Detergent Alarm	D = Door
♠ or ♥	1sec - 5 min	0 - 10	1sec - 10min	1sec - 10min	5min - 16hours A	Active -Inactive	C = Conveyor
Rinse Control ↑ or ↓	Enter Rinse Speed	Rinse Delay ↓	Rinse Limit		Rinse Alarm Active Incertive	latar On Canvaran Ding	a Limit must be ()
T or ▼	➡ 0 - 100%	0 -15sec	15sec - 70sec	5 - 75sec	Active -inactive	lote: On Conveyor Rins	se Limit must be ()
Sanitizer Set up	Enter Sanitizer Speed	Sanitizer Alarm 🖡	Sanitizer Mode				
↑ or ↓	➡ 0-100%		w/Det. Or w/Rinse				
	Enter Det, Rinse, San	<u>Det, SP, input</u> ↓	<u>Rin, SP Input</u>	■ <u>San, SP, Input</u> ■			<u> Dpen / Short</u>
t or ₽	Inputs	C + ??? Water	used with low	used with low	Enter	Enter	
			level sensor	level sensor	left to reset	left to rese	
C (+) = Concentra	tion mode w/pump runnin	g (-) = Pump stoppe	Over = times it sv	vitched do to lime o	or problem with ma	chine Open = wire	e off / No water in tank
P = Probeless				not enough deterg			on across tips
SP - Sot Point	Input - What the	proba in roading in th		0 0	•	-1 -	ı

Changing the program after the Titan has been programmed.

I-902 Rev. C-35806

SP = Set Point

Input = What the probe is reading in the tank.