

Elite Global Solutions Melamine Care and Use Instructions

To properly care for your melamine item, treat it like you would any high-quality dinnerware or displayware.

Care Guidelines:

- Commercial dishwasher safe
- Top-rack only in residential dishwashers to prevent warping and melting
- For hand washing, use a non-abrasive plastic pad or bristle brush and a mild detergent. Harsh cleaners, chlorine bleach, steel wool, and metal scouring pads are not recommended.
- If pre-soaking is necessary, use a high-quality soaking dishwashing detergent.
- Please consult your chemical specialist for the best solution made specifically for use on melamine and other plastic products

Use Guidelines:

- Not recommended for microwave or oven use
- Serrated knives should not be used on the surface as it could cause unwanted scratches and nicks.