1" X 1" & 1/2" X 1/2" SIZES



181LETCUT1, 181LETCUT12





**USER MANUAL** 





# **USER MANUAL**

Please read and comply with the instructions listed in this document. To get the best service life and performance from your appliance, clean it thoroughly before and after each use by following the instructions listed below. Minimize the use of alkaline cleaners, as they may dull the finish and cause pitting.

### **INDEX**

Safety Instructions	2
Operation	2
Cleaning & Maintenance	2
Replacement Parts	3

## **SAFETY INSTRUCTIONS**

Be careful when handling and operating the machine, as the blades are very sharp. Always keep your hands away from the blades. When not in use, use the ring pin to secure the machine in the down position.

### **OPERATION**

- 1. Remove the ring pin from the lockdown position hole.
- 2. Insert ring pin into the hole on the handle.
- 3. Lift and hold the handle in the upright position and place a head of lettuce on the blade surface.
- 4. Remove hands and fingers from the cutting area.
- **5.** Firmly push the handle down so that the push plate forces the product completely through the blades.
- 6. Clean the machine after chopping is complete using the cleaning instructions below.
- 7. Do not attempt to cut produce larger than the surface of the blade assembly.

### **CLEANING & MAINTENANCE**

- 1. Remove the ring pin and use the handle to lift the push plate off of the guide rods.
- 2. Remove the hold down clips and remove the blade assembly from the frame.
- **3.** Use a damp cloth or sponge to wipe down the frame. Clean the push plate and blade assembly thoroughly.
- 4. Make sure the frame, blade assembly, and all other components are dried thoroughly.
- 5. Replace the blade assembly, and then reattach the hold down clips.
- 6. When necessary, lubricate guide rods with mineral oil, food-grade grease, or paraffin. Do not use cooking oil.
- **7.** Replace the push plate and then return the handle to the down position. Replace the ring pin for safe storage.



**USER MANUAL** 

#### **REPLACEMENT PARTS**







1/2" x 1/2" Blade Assembly #181LETBLD12



Chain Pin Assembly #181CHAINPIN



Non-Skid Foot #181FT1



Bushing #181BUSHING2



Bumper #181BUMPER2