

WARNING: To reduce the risk of injury, read the pressure washer instruction manual and the engine instruction manual before operating pressure washer.

IF YOU EXPERIENCE ANY ISSUES WITH YOUR PRESSURE WASHER, STOP WE ARE HERE TO HELP YOU.

> Visit our website www.SimpsonCleaning.com or call 1-877-362-4271

SHOULD YOU REQUIRE ASSISTANCE WITH A PART THAT MAY BE BROKEN OR MISSING OR YOU ARE HAVING DIFFICULTY WITH ASSEMBLY OR STARTING PLEASE CONTACT US. YOUR COMPLETE SATISFACTION IS OUR PRIMARY OBJECTIVE.

QUICK SETUP GUIDE

(Letters A-C)

Install the Handle

Slide the handle assembly onto the frame. Align holes in the top handle with the mounting holes in the handle assembly. Secure with saddle bolts and knobs.



Add/Check Oil

The engine is shipped without oil. Before starting engine, add the oil provided. Check oil level prior to each use.

Refer to Engine Owner's Manual for complete procedure.



Add Gasoline

In a well ventilated outdoor area add fresh, high quality, unleaded gasoline with a pump octane rating of 86 or higher. Do not overfill. Wipe up spilled fuel before starting the engine. Refer to Engine Owner's Manual for complete procedure.







QUICK START GUIDE

(Numbers 1-12)



Connect Garden Hose to Pump Thread the garden hose to the pump inlet.



Connect High Pressure Hose to Pump

DANGER:

Connect the high pressure hose to the pump outlet.



Never run engine indoors or in poorly ventilated areas. Engine exhaust

contains carbon monoxide, an odorless and deadly gas.

Connect High Pressure Hose to Spray Gun Connect the other end of the high pressure hose to the spray gun.

• Risk of fluid injection and laceration. When using the high-pressure setting, DO NOT allow the high-pressure spray to come in contact with unprotected skin, eyes or with any pets or animals. Serious injury will occur.





Connect QC Nozzles to Spray Wand

Pull quick connect coupler back and insert nozzle. Release quick connect coupler and twist nozzle to make sure it is secure in coupler.





System Release all air from pump and high pressure hose by depressing trigger until a steady stream of water is present. Approximately 30 seconds.















Turn Water Faucet Completely On Do not run the unit without water supply connected and turned on. Use Cold Water Only.





Verify the Engine Switch is turned to the ON Position



Move the Choke to the CLOSED Position



Starter Grip Pull the recoil starter grip to start the engine.



Move the Choke to the OPEN Position

Gradually move the Choke to the OPEN Position after engine starts.



7105496 2/12 Rev0

WARNING: This Guide is not a substitute for reading the operator's manual. User must read and understand operator's manual before using this product.