

<b>820627 Compatibility Notes - 12/02/2016</b>	
<b>Model</b>	<b>Notes</b>
TUC-27D-2	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27FG	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27F-D-2	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27G	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27F	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27G-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27D-2-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27F-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27G-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27-LP-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-27G-HC-FGD01	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.