Wrapping Floss

In certain environments, especially high humidity, you may experience floss wrapping close to the head instead of flying to the bowl wall. The leather floater straps are designed to provide air lift in the bowl to correct this. Follow the instructions below to solve this problem

Figure 1 Top view



Figure 2 Side view

Shape leather floater by twisting as shown in view below. If floater will not retain its 'twist', dampen with water and allow it to dry.



Start up procedure

To reduce floss particles floating upward, leave on hi heat for the first 2 or 3 servings; then turn the heat down to desired range.