



Outperform every day.™

Technical Field Information

Stoelting® Granita Frozen Beverage Dispenser Fuse Replacement

Item Number(s): CBE117-37, CBE127-37, CBE167-37

TOOLS REQUIRED


- Phillips head screwdriver

LOCATE THE SPARE PARTS

1. Turn off and unplug the machine. Turn off and unplug the machine.



2. Remove the power side panel. Locate the bag of spare parts.



3. Locate the fuses in the bag. Fuses are color coded and amp rating is stamped on the end caps.

5 Amp Fuse
(blue and green stripes)



315 mAmp Fuse
(shades of red stripes)



REPLACE THE FUSE(S)

5 Amp Fuse Replacement

1. Locate the fuse holder.




2. Replace the fuse.
3. Replace the side panel cover.

315 mAmp Fuse Replacement

One Bowl Machine


1. Locate the fuse holder.



2. Replace the fuse(s).
3. Replace the back panel.

Two and Three Bowl Machines

1. Remove the back panel. Locate the fuses. Three bowl machines have three fuses.



2. Replace the fuse(s).
3. Replace the side and back panels



Outperform every day.™

Technical Field Information

Stoelting® Granita Frozen Beverage Dispenser Cotter Pin Replacement

Item Number(s): CBE117-37, CBE127-37, CBE167-37

TOOLS REQUIRED:


- Phillips head screwdriver
- Needle nose pliers
- Wire snipper

LOCATE THE REPLACEMENT PARTS

1. Turn off and unplug the machine.



2. Remove the power-side panel. Locate the bag of spare parts.



3. Identify the type of cotter pin in the bag.

S-Curve Pin




Straight Pin



S-CURVE PIN


1. Replace the pin.



2. Replace the panel.
3. Plug in and turn on the machine.

STRAIGHT PIN


1. Insert the new pin.




2. Use pliers to separate and bend each side of the pin so each is flat against the shaft. Use one hand to hold the shaft to keep it from rotating while using the hand to separate the pin.



3. Trim the ends.



4. Rotate the shaft to verify the trimmed pin does not interfere with other components.



5. Replace the panel.

6. Plug in and turn on the machine.



Outperform every day.™

www.vollrath.com

The Vollrath Company, L.L.C.

1236 North 18th Street
Sheboygan, WI 53081-3201 U.S.A.
Main Tel: 800.624.2051 or 920.457.4851
Main Fax: 800.752.5620 or 920.459.6573
Customer Service: 800.628.0830
Canada Customer Service: 800.695.8560

Technical Services

techservicereps@vollrathco.com
Induction Products: 800.825.6036
Countertop Warming Products: 800.354.1970
All Other Products: 800.628.0832