



T7429
Salad Fork
7 1/8"
3 Dz.



T7401
Dinner Fork
8 1/4"
3 Dz.



T7404
Dinner Knife (SH)
8 3/8"
3 Dz.



T7406
Dessert Spoon
7 1/4"
3 Dz.



T7428
US Teaspoon
6 1/8"
3 Dz.



T7411
Demitasse Spoon
4 1/2"
3 Dz.



T7413
Fish Knife
6"
3 Dz.



T7410
Euro Teaspoon
5 1/4"
3 Dz.



T7418
Iced Teaspoon
6 7/8"
3 Dz.



T7409
Soup Spoon
6 7/8"
3 Dz.



T7405
Dessert Fork
7 1/4"
3 Dz.



T7412
Fish Fork
7 7/8"
3 Dz.



T7402
Dinner Spoon
8 1/4"
3 Dz.



T7408
Dessert Knife (SH)
8 1/4"
3 Dz.