

NOTE: Faux Cast Iron is for serving and display use only. Not intended for cooking.



ILLOGICAL





MFP5 - Faux Cast Iron Fry Pan
5" dia. x 1 1/8" h., 2 3/4" Handle



MFP6 - Faux Cast Iron Fry Pan
6" dia. x 1 1/4" h., 2 3/4" Handle



MFP8 - Faux Cast Iron Fry Pan
8" dia. x 1 1/2" h., 3 1/4" Handle



MFP10 - Faux Cast Iron Fry Pan
10" dia. x 1 7/8" h., 4 1/8" Handle



MFP14 - Faux Cast Iron Fry Pan
12" dia. x 2" h., 5" Handle

Make a solid, faux cast iron appearance indoors or out.



MGP13 - Faux Cast Iron Skillet
13" x 10 1/2" x 1 7/8" h.
w/ 1 1/2" Double Sided Handles



MFP850V - Oval Faux Cast Iron Skillet
8 1/4" x 5 1/2" x 1 1/2" h.
w/ 1 1/4" Handles



MFP55
Faux Cast Iron Fry Pan
5 3/8" sq. x 1" h., w/ 5" Handle



JW4
Ramekin Sauce Bowl
4" dia. x 1 1/2" h., 5 oz.
(Only Available in Black)



JW322
3 Slot Zig Zag
6 1/2" x 5 1/8" x 2 1/4" h.
(Also Available in White)



RFP-2
Ramekin Frying Pan
2 3/4" dia. x 1" h., 2 oz.



RFP-4
Ramekin Frying Pan
3 1/2" dia. x 1 1/4" h., 4 oz.



RFP-6
Ramekin Frying Pan
4" dia. x 1 1/2" h., 6 oz.

BLACK (B)



D775PL-BC - Round Speckle Plate
7 3/4" dia. x 3/4" h.



D1075PL-BC - Round Speckle Plate
10 3/4" dia. x 3/4" h.



D512B-BC - Round Speckle Bowl
5 1/2" dia. x 2" h., 18 oz.



D878PB-BC - Round Speckle Pasta/Soup Bowl
9" dia. x 1 3/8" h., 12 oz.



Bring the great outdoors to your table.



ECO13R-BC - Bento Box
13" dia. x 2 1/2" h.



ECO13RLID-BC - Bento Box Lid
13 3/4" dia. x 1" h.



MFP55-BC - Faux Cast Iron Fry Pan
5 3/8" sq. x 1" h., 5" Handle



DC14-BC - Speckle Mug
3 5/8" dia. x 3 3/4" h., 14 oz.

