



T5329
Salad Fork
7 3/8"
3 Dz.



T5301
Dinner Fork
8 1/8"
3 Dz.



T5304
Dinner Knife (SH)
9 3/8"
3 Dz.



T5306
Dessert Spoon
7 1/4"
3 Dz.



T5328
US Teaspoon
6"
3 Dz.



T5311
Demitasse Spoon
4 1/2"
3 Dz.



T5312
Fish Fork
7 1/4"
3 Dz.



T5327
Butter Spreader
6 5/8"
3 Dz.



T5313
Fish Knife
8 1/8"
3 Dz.



T5318
Iced Teaspoon
7 1/2"
3 Dz.



T5305
Dessert Fork
7 1/4"
3 Dz.



T5302
Dinner Spoon
8 1/4"
3 Dz.



T5310
Euro Teaspoon
5 1/2"
3 Dz.



T5309
Soup Spoon
7"
3 Dz.



T5308
Dessert Knife (SH)
8 1/4"
3 Dz.