

## **USER MANUAL**



# **Digital Hanging Scales**

334HSD20

20 lb.

334HSD40

40 lb.

334HSD65

65 lb.

334HSD110

110 lb.

334HSD330

330 lb.

### **GENERAL & SAFETY INFORMATION**

- Before using the scale, please read this manual through carefully, and keep it for future use.
- For proper performance and precise measurement, use care with daily operation and maintenance. Note the following instructions:
- DO NOT overload the scale.
   This will damage the loadcell and void the warranty.
- DO NOT leave load hung on the scale for long.
   This will decrease the scale's accuracy and shorten the loadcell's life.
- Inspect shackle and hook before using
- DO NOT use the scale outdoors in inclement weather.

### **SPECIFICATIONS**

	334HSD20	334HSD40	334HSD65	334HSD110	334HSD330
CAPACITY	22 lb. / 10kg	44 lb. / 20kg	66 lb. / 30kg	110 lb. / 50kg	330 lb. / 150kg
DIVISION	0.01 lb. / 10g	0.01 lb. / 10g	0.01 lb. / 10g	0.01 lb. / 10g	0.1 lb. / 100g
UNITS	lb. / kg / N				
TARE RANGE	100% FS				
OVERLOAD	100% FS + 9d				
TEMPERATURE	32 - 104°F				
POWER	2 AAA Batteries				
AUTO OFF	3 Minutes Without Operation				

### **OPERATION GUIDE**

#### **ON/OFF KEY**

- When the scale is off, press the ON/OFF key to power on the scale.
- When the scale is on, press the ON/OFF key to power off the scale.

#### **TARE KEY**

• Under the normal weighing mode, when sale reading is stable, press the TARE key to zero out the weight.

#### **UNIT KEY**

Under normal weighing mode, press the UNIT key to shift between lb., kg, and N.

# **TROUBLESHOOTING**

SYMPTOM	POSSIBLE CAUSE	SOLUTION	
No display when ON/OFF	Battery is low	Replace batteries	
key is pressed	ON/OFF key is stuck	Long press the <b>ON/OFF</b> key	
No reaction after TARE key is pressed	Reading is not stable	Wait until reading is stable, then press <b>TARE</b> key	
Display is not at 0 when no load is present on scale	Load cell signal drifts after using for an extended time	Take down the scale, power off and power on again	
Error in weighing	Load cell signal drifts	Perform calibration	



#### **AVAWEIGH LIMITED WARRANTY**

AvaWeigh warrants its equipment to be free from defects in material and workmanship for a period of 1 year. This is the sole and exclusive warranty made by AvaWeigh covering your AvaWeigh brand equipment. A claim under this warranty must be made within 1 year from the date of purchase of the equipment. Only the equipment's original purchaser may make a claim under this warranty. AvaWeigh reserves the right to approve or deny the repair or replacement of any part or repair request. The warranty is not transferable. AvaWeigh Equipment installed in/on a food truck or trailer will be limited to a period of 30 days from the original date of purchase.

#### For Warranty Inquiries:

To obtain warranty information or make a claim against this warranty, please contact the location where you purchased the product.

- www.WebstaurantStore.com
   Call 717-392-7472. You must have your order number ready when contacting.
- The Restaurant Store
   Please contact your local store directly.
- www.TheRestaurantStore.com
   Call 717-392-7261. You must have your order number ready when contacting.
- Clark Food Service Equipment, PRO Marketplace, Hometown Provisions

Please contact your account manager directly. If you do not know your account manager, please call 717-392-7363 for CFSE and Pro Marketplace or 717-464-4165 for Hometown Provisions

Failure to contact the designated location prior to obtaining equipment service may void your warranty.

AvaWeigh makes no other warranties, express or implied, statutory or otherwise, and **HEREBY DISCLAIMS ALL** 

IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.

#### This Limited Warranty Does Not Cover:

- Equipment sold or used outside the Continental United States.
- AvaWeigh has the sole discretion on wearable parts not covered under warranty.
- Equipment not purchased directly from an authorized dealer.
- Equipment used for residential or other noncommercial purposes.
- Equipment that has been altered, modified, or repaired by anyone other than an authorized service agency.
- Equipment for which a valid purchase cannot be verified. Please have your order number or receipt, and serial number (if available) when making a claim.
- Damage or failure due to improper installation, improper utility connection or supply, and issues resulting from improper ventilation or airflow.
- Defects and damage due to improper maintenance, wear and tear, misuse, abuse, vandalism, or Act of God.

Any action for breach of this warranty must be commenced within 1 year of the date on which the breach occurred. No modification of this warranty, or waiver of its terms, shall be effective unless approved in a writing signed by the parties. The laws of the Commonwealth of Pennsylvania shall govern this warranty and the parties' rights and duties under it. AvaWeigh shall not under any circumstances be liable for incidental or consequential damages of any kind, including but not limited to loss of profits.

