
INSTALLATION INSTRUCTIONS **DROP-IN BAIN MARIE** STYLE HEATED TANK MODEL HT-400


ELECTRICAL

WATTS			AMPS PER LINE 3 PHASE			FIELD WIRING GAUGE		
	L1	L2	L3	SINGLE PHASE	3 PHASE	1 PHASE	RATING	
3600	8.7	15.0	8.7	17.3	12 AWB Cu	12 AWB Cu	90°C	INCHES
4800	10.0	17.3	10.0	20.0	12 AWB Cu	12 AWB Cu	90°C	(MM)
	4800	4800 10.0		4800 10.0 17.3 10.0	3600 8.7 15.0 8.7 17.3 4800 10.0 17.3 10.0 20.0	3600 8.7 15.0 8.7 17.3 12 AWB Cu 4800 10.0 17.3 10.0 20.0 12 AWB Cu	3600 8.7 15.0 8.7 17.3 12 AWB Cu 12 AWB Cu 4800 10.0 17.3 10.0 20.0 12 AWB Cu 12 AWB Cu	3600 8.7 15.0 8.7 17.3 12 AWB Cu 12 AWB Cu 90°C 4800 10.0 17.3 10.0 20.0 12 AWB Cu 12 AWB Cu 90°C

UNITS ARE SHIPPED THREE PHASE AND ARE FIELD CONVERTIBLE TO SINGLE PHASE

CUTOUT DETAILS





INSTALLATION INSTRUCTIONS

INSTALLER MUST MEET CONDITIONS OF ACCEPTABILITY OUTLINED BELOW UPON INSTALLATION:

1. Required installation clearances: Wooden and Metal Installation: DO NOT install closer than 4 1/8 inches to front wall, 1 inch to back and side walls, and 6 3/4 inches to surface below the unit.

Unit shall be accessible for servicing from the bottom.
If storage is to be used underneath the unit, it is recommended that a baffle be placed 8 1/2 inches below the unit to avoid contact with elevated temperatures.

TO FABRICATE: 1. Lay out "cutout" dimensions on countertop and front apron. 2. Lay out and fabricate control panel holes in counter


apron using the control box as a template. 3. Cut out holes.

TO INSTALL: IMPORTANT - DO NOT disconnect lead wires from the Master Control Panel when making installation. 1. Tilt and pass Control Panel and electrical box through the counterton cutout, then through the apron cutout. the countertop cutout, then through the apron cutout. Lower modular section into countertop cutout and position

RECOMMENDATION: Before final seating of modular section to countertop, apply a bead of silicone adhesive/sealant to the underside of gasket supplied on the mounting flange.

From underneath, insert screwdriver into slots in Wellslock frame and twist ears outward (clockwise) as required to secure flange tightly to countertop.
Mount Control Box to apron cutout as shown in drawing.
Mount Control Panel onto electrical box using the screws supplied

screws supplied.



WARMER FLANGE GASKET WELLSLOK SCREWDRIVER

COUNTERTOP



TO PLUMB:

A drain with valve is supplied on all units. Location of the valve handle is at the discretion of the fabricator (see drawing).
Connect 1" drain connection to a suitable drain line.

TO WIRE:

1. Final connection is accomplished by bringing proper power supply leads (see 'WIRING REQUIREMENTS' label) through conduit knockout to terminal block supplied within the Master Control Panel. Check nameplates for voltage and phase.

NOTES:

BAIN MARIE STYLE HEATED TANKS ARE DESIGNED FOR WET OPERATION ONLY.

INSTALLATION MUST MEED LOCAL PLUMBING AND ELECTRICAL CODES.